



Start = 405 MHz

Center = 430 MHz
Span = 50 MHz

Stop = 455 MHz

S21 Smith S12 Smith
S11 Smith S22 Smith